

Qwizdom® STUDENT REMOTE

Q# 008

Q#: Displays the current question number.



Right/Wrong Indicator: Lets students know if response is correct or incorrect.

ID# 0037

ID#: Displays the remote number.



Menu/Power: Press to view menu options. Here you can enter a different session ID or search again for the host. Hold down to turn remote on or off.




Send: Press to submit answer.



Battery Power: Indicates how much life is left on the battery.



Decimal: Press between two numbers to indicate a decimal.



Clear: Press to delete last character.



Left/Right: Press to navigate between menu options, answer choices & question numbers.



Fraction: Press between two numbers to indicate a fraction.



Minus: Press to indicate a negative number.

Q4_{RF}

Remote Setup

Before you can use your remotes you must specify the remote type within the Remote Options window. The following steps show how to set up and test your Q4 remotes:

To set up & test remotes:

- Plug the Receiver into an open USB port.
- Insert Interact CD-Rom & install drivers.
- Open Qwizdom Interact.
- Click on the *Remotes* button. The Remote Options window will appear.
- Click on the *Change* button.
- Select *Q4 RF Remote*.
- Check the *Teacher Remote* box if using a teacher remote.
- Under *Student Remotes*, specify the lowest and highest remote numbers used in the set.
- Check *Classroom Set* if your set of remotes are used only in a single classroom. This uses a fixed number for every remote and does not require students to enter session & student ID's during activities.
- Check *Roaming or Student Owned* if remotes are used in more than 1 classroom with different receivers. This reassigns a new number to remotes during every activity and requires that students enter session & student ID numbers.
- If you selected *Classroom Set*, turn on remotes & click *Assign Fixed Numbers* to assign remotes a fixed number. A session ID number will appear on-screen. Enter this number on each remote & press *Send*.
- Click on *Test*. The Test Remote window will appear with each remote number listed in a gray box.
- Hit any key on a remote to test it. If the remote is working properly, the box containing the remote number will change the color to blue.
- When you are done, select *Close* to exit the Test Remote window. You will be taken back to the Remote Options window.
- Click *OK* to exit.